


068-01-504

Montageanweisung
ratiopacPRO /-air
Bandgriff


Assembly instructions
ratiopacPRO /-air
Expanding handle

Instructions de montage
ratiopacPRO /-air
Poignée souple



068-01-515

Hinweis:
Traglast des Bandgriffes 20 kg
Note:
Load-carrying capacity of expanding handle 20 kg
Remarque:
Charge admissible 20 kg



068-01-516